

SMA Male to RPSMA Male Adapter

WRL-09233



- [Description](#)

This is an inner thread (outer nut) adapter that will connect to any of our wireless boards or interface cables and allow you to use an antenna/cable that has an outer thread configuration.

You should not need this adapter with any of our antennas or dev boards. These adapters are listed only to help SparkFun users that have rare or odd antenna coupling needs. Be sure to check out the SMA connector tutorial [here](#) for more information on SMA connectors.

Supported Connections: Any RP-SMA or SMA antenna, cable, or connector that uses an outer thread design. All Spark Fun antennas use an inner thread (outer nut) design.