

ROCKER SWITCH 2P 2C (15*21) (RESET)

Momentary push button KCD1-101 2PIN - 250V 6A - monostable - RESET

-
- A simple design momentary monostable push-button with a rectangular red push-button. The KCD1-101 switch can be used to control as a RESET button, which generates an impulse to the installation, e.g. the lighting turns on or off.

Product description

A simple, monostable momentary push-button in a plastic casing with a rectangular red push-button, mounted to the casing.

The KCD1-101 switch can be used to control the RESET button, which generates an impulse to the installation as a result, e.g. the lighting turns on or off. Both switching on and off the lighting requires pressing a key.





Technical data

- single, monostable
- terminals for soldering wires
- number of 4.8mm pins: 2
- current / voltage: 10A/125V, 6A/250V
- key color: red - Black
- housing dimensions: 21 x 15 x 15 mm



Included

- Momentary push button KCD1-101 2PIN - 250V 6A - monostable - 1pc