


# ADP AVR ISP



10 Pin to 6 Pin Adapter for AVRISP MKII USBASP STK500

## Characteristics:

ISP interface converter can be used for Arduino development board.

AVR MCU development board can be used to download interface converter.


AVRISP USBASP STK500 programmer standard interface to 6PIN 10PIN Convert standard interface

## Package Includes:

1 \* 10 Pin Converted To Standard 6 Pin Adapter Board

### ISP 10pin

1. MOSI	● ●	2. VTG
3. X	● ●	4. X
5. RST	● ●	6. X
7. SCK	● ●	8. GND
9. MISO	● ●	10. GND



### ISP 6pin

1. MISO	● ●	2. VTG
3. SCK	● ●	4. MOSI
5. RST	● ●	6. GND

### PDI

1. DATA	● ●	2. VTG
3. X	● ●	4. X
5. CLK	● ●	6. GND

### TPI

1. DATA	● ●	2. VTG
3. CLK	● ●	4. X
5. RST	● ●	6. GND